

SETTING INSTRUCTIONS

- 0 - Operating (working) flush plate mode
 - always after setting
- 1 - Small flush colour (white, yellow, green, red, blue)
- 2 - Large flush colour (white, yellow, green, red, blue)
- 3 - Person detection colour (white, yellow, green, red, blue)
- 4 - Brightness
- 5 - Small flush duration (1.0, 1.5, 2.0, 2.5, 3.0 s)
- 6 - Large flush duration (4.0, 4.5, 5.0, 5.5, 6.0 s)
- 7 - Detection light / Permanent light (Red, White)
- 8 - Duration of light after end of detection (20 s - 1 h)
- 9 - Person detection distance (50 - 120 cm)
- A - Sensor sensitivity for WC flushing (0 - 5 cm)
- E - Reset to factory settings
- F - Saving configuration